






Fitting Kit T-Tracks


Load-Lid



Despatch List:


ID#	DESCRIPTION	IMAGE	QTY
[1]	T-Track Extrusion (PRT-70913-01)		2
[2]	Extrusion End Cap (PRT-000486)		4
[3]	M6 x 16mm Btn Head Bolt		10
[4]	M6 Flat Washer		10
[5]	M6 Nyloc Nut		10

1



Place each T-Track on the top of your Load Lid
Ensure each T-Track are vertical and equal distance top and bottom from each other (parallel)
Mark each extremities hole of each T-Track

2




Drill 6.5 mm holes by beginning on the sides ones. Then add a hole in the center of both extremities and one hole between center and each extremities

Important note:

Make sure T-Track is held firmly whilst drilling

3



Drill 6.5 mm holes by beginning on the extremities ones. Then add a hole in the center of both extremities and one hole between center and each extremities.


Important note:

Make sure T-Track is held firmly whilst drilling

Tip:


You can put a bolt and a nut on each extremities before drilling the others holes in the middle to avoid T-Track moving

4



Take off each T-Track from the Lid and run a bead of sealer along the bottom face

5



Place each T-Track on the Lid and bolt down using the following fasteners:


[3] 5x M6x16 Bt Hd Bolt

[4] 5x M6 Flat Washer

[5] 5x M6 Nyloc Nut

Repeat the step for the second T-Track

6



Use 4 end caps [2] at the end of each T-Track [1] lengths with silicone.

Your T-Tracks product is now fully fitted and ready for use.
Thanks again for choosing Utemaster and don't forget to keep checking our website for our latest innovations!